


繁 安裝複合感測器

簡 安裝复合感测器


進階版配備(ANT+ 無線踏頻/速度複合感測器)
进阶版配备(ANT+ 无线踏频/速度复合感测器)

複合感測器、踏頻磁鐵、速度磁鐵安裝位置圖
复合感测器、踏频磁铁、速度磁铁安装位置图

- 設定E7與複合感應器連接
设定E7与复合感应器连接
- ← 表示長按
表示长按
- ↶ 表示短按
表示短按
- ➡ 表示短按 ↻
表示短按 刷新




① 長按進入設定選單
长按进入设定选单



② 選擇7.自行車設定
选择7.自行车设定



③ 短按進入自行車1設定
短按进入自行车1设定




④ 短按選擇複合計
短按选择复合计



⑤ 短按變更設定值
短按变更设定值



⑥ 短按開啟複合計
短按开启复合计



⑦ 短按進入配對搜尋
短按进入配对搜寻




⑧ 配對搜尋中
配对搜寻中



⑨ 旋轉踏柄啟動複合感測器
等待複合計顯示配對號碼
旋转踏柄启动复合感测器
等待复合计显示配对号码



⑩ 短按儲存配對號碼
短按储存配对号码



⑪ 確認配對成功後退出設定
确认配对成功后退出设定



短按

En Install Combo Sensor

Advanced model optional accessory
(ANT+ Speed/Cadence Combo sensor)

Installation position
of ComboSensor, Speed magnet, and Cadence magnet

- Connecting E7 with Combo Sensor
- ← Long press 3 sec
- ↶ Short press
- ➡ Short press ↻




① Enter MENU Mode




② Short press to select 7. Bike Setting



③ Short press to enter BIKE1 Mode




④ Short press to select CMB (Combo Sensor)




⑤ Short press to change CMB setting



⑥ Short press to set CMB ON



⑦ Short press to connect CMB




⑧ Scanning CMB



⑨ Rotate crank and wait for CMB ID is displayed. If CMB ID is not correct, press DATA2/BIKE to rescan



⑩ Short press to save Settings



⑪ Make sure CMB is ON with ID displayed and then exit CMB setting